



F&F Filipowski sp. j.  
 Konstytucyjna 79/81 95-200 Pabianice  
 phone/fax: (+48 42) 215 23 83 / 227 09 71 POLAND  
 http://www.fif.com.pl e-mail: fif@fif.com.pl

PULSE METER

CLI-11T  
 230V

**WARRANTY.** The F&F products are covered by a warranty of the 24 months from the date of purchase. Effective only with proof of purchase. Contact your dealer or directly with us. More information how to make a complaint can be found on the website: [www.fif.com.pl/reklamacja](http://www.fif.com.pl/reklamacja)



Do not dispose of this device to a garbage bin with other unsorted waste! In accordance with the Waste Electrical and Electronic Equipment Act any household electro-waste can be turned in free of charge and in any quantity to a collection point established for this purpose, as well as to the store in the event of purchasing new equipment (as per the old for new rule, regardless of brand). Electro-waste thrown in the garbage bin or abandoned in the bosom of nature pose a threat to the environment and human health.

**PURPOSE**

Pulse meter is intended for counting AC/DC voltage signals, generated by additional peripheral devices in order to determine the number of carried out working cycles in automatics systems, e.g. in order to control the number of press strokes, the number of revolutions of a rotating device, the number of components leaving the production line, etc.

**FUNCTIONING**

CLI-11T meter is an electronic, one-way meter, enabling the counting of pulses from 0 to 999999 range (six digits). It is equipped with RESET input for the connection of external button and RESET input for the connection of an external button, enabling the resetting of the meter state for any value.

**ASSEMBLY**

1. Take OFF the power.
2. Unscrew the nut and remove the attachment plate.
3. Embed meter in the assembly hole, attach plate and tighten the cap screws.
4. To joints U (read input) connect the voltage which is reading signal (impulse).
5. To RESET joints connect monostabile close button. ATTENTION! Do not connect any voltage..

**TECHNICAL DATA**

|                           |                        |
|---------------------------|------------------------|
| supply (non-voltage type) | internal battery       |
| battery life              | 5 years                |
| read input voltage        | 110÷240V AC/DC         |
| max coting frequency      | 200Hz                  |
| input RESET               | non-voltage type       |
| display                   | 8 characters / h=6,7mm |
| precision                 | 1%±1digit)             |
| working temperature       | -10÷40°C               |
| dimensions                | 48×24×52mm             |
| fixing hole               | 45×23mm                |

**WIRING DIAGRAM**

